Pedicraft Bassinets

Operations Manual

For technical assistance call 800-223-7649

Pedicraft, Inc. 4134 St. Augustine Road Jacksonville FL 32207

800-223-7649 904-396-9627 fax 904-346-3947 www.pedicraft.com



Rev. 4 012210

Safety Guidelines

- Do not transport infant with acrylic basket in elevated position.
- Lock casters when not in transit.
- Optional Conductive Casters: Contact with oil should be avoided. Resistance of
 electrostatic conductive rubber tread compounds may increase with age, service and
 contact with lubricants. Some waxes, polishes and cleaning materials used for floor
 maintenance may adversely affect the resistance of the material. Since the
 manufacturer has no control over these conditions, no guarantee of the continuing level
 of conductivity is made. It is recommended that the resistance of the conductive
 assembly be initially tested, prior to use, and thereafter tested routinely at intervals of
 not more than one month, as a check on resistance value.

Cleaning Instructions

FAILURE TO FOLLOW CLEANING INSTRUCTIONS MAY VOID WARRANTY Use a damp sponge or soft cloth with mild soap or detergent. **Be sure to follow manufacturer's directions for diluting cleaning solutions.** Rinse with clean water and dry.

Additional Cleaning Instructions for Bassinet Carts

You may also use stainless steel cleaners such as *Stainless Steel Magic*. Follow manufacturer's directions.

Additional Cleaning Instructions for Bassinet Mattress Pad

To disinfect: Remove mattress pad from Bassinet Basket. Use disinfectants recommended by Herculite, either phenolic type or quaternary type. Iodophor type disinfectants are not recommended as staining may result.

Additional Cleaning Instructions for Acrylic Bassinet Basket

Do not expose to temperatures higher than 140° F.

Do not use window sprays, all-purpose surface cleaners or abrasive scouring cleaners.

Do not use any cleaner if the label advises against use on acrylic plastics. Do not use solvents such as acetone, gasoline, benzene, toluene, chlorinated hydrocarbons or lacquer thinner for cleaning any acrylic products since these will permanently damage the acrylic surface.

Residue from adhesive tape may be removed with mineral spirits. Use with caution and with strict attention to manufacturer's directions. Any residual film left behind should be washed off immediately.

Bassinet Latch Repair Instructions

Models #18215, 18218, 18250 - order repair kit # 91805

Model #18270 - order repair kit #91806

- 1. Open Drawer.
- 2. Push Knob to right to position screw at opening inside drawer.
- Unscrew Knob and remove both Knob and screw.
- 4. Pull black plastic Latch Slide from left. Remove Latch Slide and Spring.
- 5. (If Spring does not come out with the Slide, remove drawer, turn sideways and shake drawer until Spring falls out.)
- Insert new Spring into slot at end of new Latch Slide.
- 7. Position Slide so that angled edge faces in the direction the drawer will close.
- Insert Slide and Spring into opening.
- 9. Reinsert screw from inside Drawer and attach Knob. Tighten securely. (Lok-Tite applied to screw before attaching Knob is recommended.)

Warranty

Pedicraft, Inc. guarantees Bassinets to be free of defects in workmanship or materials for a period of three years from the date of shipment to the purchaser. In case any purchaser finds a defect in workmanship or materials, promptly notify Pedicraft at 800-223-7649.

The purchaser must return the article as per instructions and Pedicraft will replace, repair or refund the purchase price, at its sole discretion. All replaced or repaired items will be shipped freight prepaid from the factory to the purchaser. Any extra costs resulting from failure to obtain prior shipping instructions from Pedicraft will be borne by the customer.

Any changes or modifications of the equipment by the purchaser without the express written permission of Pedicraft, Inc., will void this warranty. Failure to follow cleaning instructions may void warranty.



800-223-7649